

- Clutch with hydraulic release device 1

REMOVING-REFITTING

- Lining - Driven disc 2
- Refitting 3

CLUTCH OPERATION

- Thrust bearing 3
- Selector fork 4
- Sleeve - Clutch pump 5
- Operating cylinder 8

CLUTCH WITH HYDRAULIC RELEASE MECHANISM

In order to reduce the force exerted on the clutch pedal and to facilitate the release mechanism, a hydraulic device has been fitted. This device comprises a reservoir (1), a pump (2) fixed to the pedals and an operating cylinder (3) fixed to the bell housing by a bracket (4).


The use of a hydraulic device allows improved and more reliable operation compared with a mechanical device; in addition as the release mechanism has been made more gradual there are no longer any jerking, particularly when high torques are being transmitted.

A more comfortable ride is obtained because the vibrations sent by the power unit due to the damping effect of the oil are reduced.

The adoption of this device allows a constant adjustment of the clutch pedal height.

On the DELTA HF 16 V the clutch assembly has a traction release mechanism; this name stems from the fact that when the pedal is pressed the clutch is pulled by the coupled thrust bearing rather than thrust in the conventional way.


This type of clutch has been used because due to the high torque to be transmitted the size of the clutch assembly has to be increased in order not to alter the force on the pedal during the release action.




18.

NOTE In order to remove the clutch the gearbox-differential unit has to be removed

With the gearbox-differential unit removed, proceed as follows:



P1L02AC01




P1L02AC02


Removing clutch assembly

LINING - CLUTCH PLATE

If the driven disc lining is excessively worn then the complete clutch plate has to be replaced




P1L02AC03



P1L02AC04

If there are signs of wear, overheating or deep grooves in the linings, replace the assembly



P1X003C05



Driven disc alignment check

The run out on the disc must not be more than 0.25 mm.



P1X004C04

Removing clutch thrust bearing


REFITTING

Alignment of driven disc for refitting clutch assembly using centering tool


THRUST BEARING

Positioning thrust bearing on gearbox main shaft


The bearing should not show signs of sticking or noisiness during rotation or else it must be replaced



P1L03AC01




P1L03AC02



P1X004C03

18.




P1X005C01



NOTE *In order to refit the gearbox to the engine the clutch release fork must be suitably fixed positioning it as shown in the diagram*

Fixing clutch release fork




P1X005C02



NOTE *After refitting the gearbox, move the selector fork in the direction shown by the arrow to allow the thrust bearing to be positioned in its seat*

Positioning thrust bearing in its seat



P1X005C04

P1X005C03



SELECTOR FORK


Removing-refitting selector fork

18.




P1X008C04

Removing-refitting clutch pedal return spring



P1X008C05


Removing-refitting clutch pump




P1X008C06

View of clutch pump

18.




P1X010C01



P1X010C02




Removing-refitting supply union and seal



P1X010C03

Clutch pump components



P1L08AC01




OPERATING CYLINDER

Removing-refitting clutch operating cylinder

Remove the circlip fixing the operating cylinder to the mounting bracket and extract the operating cylinder after having disconnected the flexible oil pipe

18.



Removing-refitting bleed screw



Clutch operating cylinder components

P1X014C02

When the hydraulic system components have been refitted carry out the:



Bleeding of the air from the clutch